




N O T E


THIS DRAWING AS AN INSTRUMENT OF SERVICE. IS THE PROPERTY OF R E S Y S T A


AND AS SUCH MUST NOT BE REPRODUCED OR COPIED IN PART OR IN WHOLE WITHOUT THE PERMISSION OF THE AUTHOR.

ALUMINUM TRIM HORIZONTAL SIDING DETAIL

	SPECIFICATION		SHEET CONTENT	SHEET SIZE	DRAWING NO.	CONTINENT
	TYPICAL DRAWING DETAIL		ISOMETRIC VIEW	A3	ATHSD-01	RESYSTA
			BLOW-UP DETAIL			
				DATE	REVISION	$V \subset V$
	CAD BY:	CHECKED BY:		02.04.22	0	7317
	M.T.C.	C.R.E		03.01.23	U	










Note:


An H-Channel should be installed at each board abutment joint to cover the ends of the Resysta siding board. This is a option for installations using 3 or more boards abutted end-to-end






Inside corner trim should be pre-applied prior to installing siding boards. The starter strip for the first board should be installed butted against the corner trim, not overlapping the corner trim attachment. Follow the gap guide when installing the siding board to allow for expansion and contraction within the inside corner trim.






Note:

Outside corner trim should be pre applied prior to installing siding boards. The starter strip for the first board should be installed butted against the corner trim, not overlapping the corner trim attachment The siding board end that is inserted into the outside corner should be miter cut at a 45 degree angle to match up with the outside corner internal web.





Note:

When a siding board in either a horizontal or vertical application terminates into a wall, eave, window, door etc. a J-channel should be used to cover the exposed end of the siding board. The J-channel should also be used along the bottom of a vertical installation. J-channel trim should be pre-applied prior to installing siding boards.

